

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://superq.nt-rt.ru/> || squ@nt-rt.ru

High Vacuum Manual Angle Valve



EVGD Series High Vacuum Manual Angle Valve is powered by the hand turning handle, and is connected to the valve plate through the mechanism, and drives the valve plate to open and close.

The valve features reasonable structure design, beautiful appearance, and has the advantages of stable action, small volume, reliable use, good sealing performance and long service life. It is one of the preferred valves for vacuum equipment.

The medium of the valve should be a non-corrosive gas.

EVGD Series High Vacuum Manual Angle Valve, DN6-DN50

Model		EVGD-J(6~10)B(KF)S	EVGD-J16B(KF)S	EVGD-J25B(KF)S	EVGD-J40B(KF)S	EVGD-J50B(KF)S
Pressure Range	Pa	1x10 ⁻⁶ Pa~1.2x10 ⁵ Pa (sealed with bellows)				
Inside nominal diameter	mm	6~10	16	25	40	50
Leak rate	Pa·L/s	≤1.3x10 ⁻⁷				
Service life until first maintenance	time	1000 000 (sealed with bellows) 600 000 (sealed with viton O ring)				
Heating temperature(Valve body)	°C	≤120				
Opening / closing	s	Manual operation time				

time		
Position indicator of the valve	—	Mechanical instructions
Installation orientation	—	Any
Ambient temperature	°C	5~40

EVGD Series High Vacuum Manual Angle Valve, DN63-DN160

Model		EVGD-J63B(I SO-K)S	EVGD-J80B(I SO-K)S	EVGD-J100B(I SO-K)S	EVGD-J160B(I SO-K)S
Pressure Range	Pa	1x10 ⁻⁶ Pa~1.2x10 ⁵ Pa(Bellow sealed) 1x10 ⁻⁵ Pa~1.2x10 ⁵ Pa(Viton o-ring sealed)			
Inside nominal diameter	mm	63	80	100	150
Leak rate	Pa·L/s	≤1.3x10 ⁻⁷			
Service life until first maintenance	time	200000			
Heating temperature(Valve body)	°C	≤120			
Opening / closing time	s	Manual operation time			
Position indicator of the valve	—	Mechanical instructions			
Installation orientation	—	Any			
Ambient temperature	°C	5~40			

Product 3D display

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://superq.nt-rt.ru/> || squ@nt-rt.ru