

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13


Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

<https://superq.nt-rt.ru/> || squ@nt-rt.ru


04 ADAPTOR FLANGE SERIES

CF-ISO Adaptor




EV Part Number.	Size	A	B	C	Material	Order Number
EVCF63S63A	CF63-ISO63	114	95	110	304SS	C900
EVCF100S80A	CF100-ISO80	152	110	112	304SS	C901
EVCF100S100A	CF100-ISO100	152	130	112	304SS	C902
EVISO160C150A	CF150-ISO160	202	180	114	304SS	C903
EVISO200C200A	CF200-ISO200	253	240	116	304SS	C904

CF-KF Adaptor




V Part Number.	Size	A	B	C	Material	Order Number
EVCF16K10A	CF16-KF10	34	30	42	304SS	C905
EVCF16K16A	CF16-KF16	34	30	42	304SS	C906
EVCF25K25A	CF25-KF25	54	40	42	304SS	C907
EVCF35K10A	CF35-KF10	70	30	46	304SS	C908
EVCF35K16A	CF35-KF16	70	30	46	304SS	C909
EVCF35K25A	CF35-KF25	70	40	46	304SS	C910
EVCF35K40A	CF35-KF40	70	55	46	304SS	C911
EVCF50K40A	CF50-KF40	86	55	46	304SS	C912
EVCF50K50A	CF50-KF50	86	75	46	304SS	C913
EVCF63K50A	CF63-KF50	114	75	50	304SS	C914

ISO-KF Adaptor




EV Part Number.	Size	A	B	C	Material	Order Number
EVCFISO63K16A	ISO63-KF16	95	30	46	304SS	C915
EVCFISO63K25A	ISO63-KF25	95	40	46	304SS	C916
EVCFISO63K40A	ISO63-KF40	95	55	50	304SS	C917
EVCFISO63K50A	ISO63-KF50	95	75	50	304SS	C918
EVCFISO80K16A	ISO80-KF16	110	30	46	304SS	C919
EVCFISO80K25A	ISO80-KF25	110	40	46	304SS	C920
EVCFISO80K40A	ISO80-KF40	110	55	50	304SS	C921
EVCFISO80K50A	ISO80-KF50	110	75	50	304SS	C922
EVCFISO100K16A	ISO100-KF16	130	30	46	304SS	C923
EVCFISO100K25A	ISO100-KF25	130	40	46	304SS	C924
EVCFISO100K40A	ISO100-KF40	130	55	50	304SS	C925
EVCFISO100K50A	ISO100-KF50	130	75	50	304SS	C926
EVCFISO160K16A	ISO160-KF16	180	30	46	304SS	C927
EVCFISO160K25A	ISO160-KF25	180	40	46	304SS	C928
EVCFISO160K40A	ISO160-KF40	180	55	50	304SS	C929
EVCFISO160K50A	ISO160-KF50	180	75	50	304SS	C930

CF Reducing Adaptor-Fixed




EV Part Number.	Size	A	B	C	D	Material	Order Number
EVCF35R16A	CF35-CF16	69.5	33.8	76.2	19.05	304SS	C931
EVCF63R16A	CF63-CF16	113.6	33.8	76.2	19.05	304SS	C932
EVCF63R35A	CF63-CF35	113.6	69.5	76.2	38.1	304SS	C933
EVCF100R35A	CF100-CF35	151.6	69.5	76.2	38.1	304SS	C934
EVCF100R63A	CF100-CF63	151.6	113.6	76.2	63.5	304SS	C935
EVCF150R35A	CF150-CF35	202.5	69.5	76.2	38.1	304SS	C936
EVCF150R63A	CF150-CF63	202.5	113.6	76.2	63.5	304SS	C937
EVCF150R100A	CF150-CF100	202.5	69.5	76.2	101.6	304SS	C938

CF Reducing Adaptor-Small Flange Rotatable




EV Part Number.	Size	A	B	C	D	Material	Order Number
EVCF35R16AR	CF35-CF16	69.5	33.8	76.2	19.05	304SS	C939
EVCF63R16AR	CF63-CF16	113.6	33.8	76.2	19.05	304SS	C940
EVCF63R35AR	CF63-CF35	113.6	69.5	76.2	38.1	304SS	C941
EVCF100R35AR	CF100-CF35	151.6	69.5	76.2	38.1	304SS	C942
EVCF100R63AR	CF100-CF63	151.6	113.6	76.2	63.5	304SS	C943
EVCF150R35AR	CF150-CF35	202.5	69.5	76.2	38.1	304SS	C944
EVCF150R63AR	CF150-CF63	202.5	113.6	76.2	63.5	304SS	C945
EVCF150R100AR	CF150-CF100	202.5	69.5	76.2	101.6	304SS	C946

KF-KF Straight pipe Reducing Adaptor




EV Part Number.	A	1	2	L	Material	Order Number
EVKF16R10A	10	KF16	KF10	40	Al	C947
EVKF25R16A	16	KF25	KF16	40	Al	C948
EVKF40R16A	16	KF40	KF16	40	Al	C949
EVKF40R25A	25	KF40	KF25	40	Al	C950
EVKF50R40A	40	KF50	KF40	40	Al	C951
EVKF16R10S	10	KF16	KF10	40	304SS	C952
EVKF25R16S	16	KF25	KF16	40	304SS	C953
EVKF40R16S	16	KF40	KF16	40	304SS	C954
EVKF40R25S	25	KF40	KF25	40	304SS	C955
EVKF50R40S	40	KF50	KF40	40	304SS	C956

KF-KF Conical Reducing Adaptor




EV Part Number.	Size	A	B	C	Material	Order Number
EVKF25R16A	K25-KF16	40	30	40	304SS	C957
EVKF40R16A	KF40-KF16	55	30	40	304SS	C958
EVKF40R25A	KF63-KF25	55	40	40	304SS	C959
EVKF50R16A	KF50-KF35	75	30	40	304SS	C960
EVKF50R25A	KF50-KF25	75	40	40	304SS	C961
EVKF50R40A	KF50-KF40	75	55	40	304SS	C962

ISO-KF Conical Reducing Adaptor




EV Part Number.	Size	A	B	C	Material	Order Number
EVISO80K40RA	ISO80-KF40	110	55	63	304SS	C963
EVISO100K40RA	ISO100-KF40	130	55	63	304SS	C964
EVISO80K50RA	ISO80-KF50	110	75	63	304SS	C965
EVISO100K50RA	ISO100-KF50	130	75	63	304SS	C966

ISO-ISO Conical Reducing Adaptor



EV Part Number.	Size	A	B	C	Material	Order Number
EVISO80R63A	ISO80-ISO63	110	95	63	304SS	C967
EVISO100R63A	ISO100-ISO63	130	95	63	304SS	C968
EVISO100R80A	ISO100-ISO80	130	110	63	304SS	C969
EVISO160R63A	ISO160-ISO63	180	95	63	304SS	C970

ISO Reducing Adaptor



EV Part Number.	Size	L	1	2	Material	Order Number
EVISO80-63RA	ISO80-ISO63	50	ISO80	ISO63	304SS	C971
EVISO100-63RA	ISO100-ISO63	50	ISO100	ISO63	304SS	C972
EVISO100-80RA	ISO100-ISO80	50	ISO100	ISO80	304SS	C973
EVISO160-63RA	ISO160-ISO63	50	ISO160	ISO63	304SS	C974
EVISO160-80RA	ISO160-ISO80	50	ISO160	ISO80	304SS	C975
EVISO160-100RA	ISO160-ISO100	50	ISO160	ISO100	304SS	C976
EVISO200-63RA	ISO200-ISO63	80	ISO200	ISO63	304SS	C977
EVISO200-80RA	ISO200-ISO80	80	ISO200	ISO80	304SS	C978
EVISO200-100RA	ISO200-ISO100	80	ISO200	ISO100	304SS	C979
EVISO200-160RA	ISO200-ISO160	80	ISO200	ISO160	304SS	C980
EVISO250-63RA	ISO250-ISO63	80	ISO250	ISO63	304SS	C981
EVISO250-80RA	ISO250-ISO80	80	ISO250	ISO80	304SS	C982
EVISO250-100RA	ISO250-ISO100	80	ISO250	ISO100	304SS	C983
EVISO250-160RA	ISO250-ISO160	80	ISO250	ISO160	304SS	C984
EVISO250-200RA	ISO250-ISO200	80	ISO250	ISO200	304SS	C985

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

<https://superq.nt-rt.ru/> || squ@nt-rt.ru